

# Comeback

## Collection Comeback

### Technical data sheet

<b>GENERAL</b>		
Composition	80%PL+11%PL REC+4%CO + 5%CO REC	
Roll width	140cm	
Roll length	40m	
Weight	780gr/m	
<b>TESTS</b>	<b>METHOD</b>	<b>RESULT / U.M.</b>
Martindale abrasion	UNI EN ISO 12947-2	200.000 cycles
Pilling	UNI EN ISO 12945-2	5
Colour fastness to light	UNI EN ISO 105 B02	5-6
Colour fastness to rubbing	UNI EN ISO 105 X12	4-5 (dry/wet)
Seam slippage resistance	UNI EN ISO 13936-2 (mm)	warp+weft: 1,00
Burning behaviour	UNI EN ISO FR 1021 part 1	Pass (part 2 upon request)
<b>CARE</b>		
 <b>PERFORMANCE+</b>		<ul style="list-style-type: none"> <li>° EASY TO CLEAN</li> <li>° LONG LASTING</li> <li>° ANTIMICROBIAL/SANITIZED</li> <li>° ANTIBACTERIAL ACTIVITY</li> </ul> 
<b>ENVIRONMENTAL COSIDERATIONS</b>		
		<ul style="list-style-type: none"> <li>° RECYCLED CONTENT</li> <li>° PFAS FREE</li> <li>° OEKOTEX COMPLIANT</li> <li>° REACH COMPLIANT</li> </ul>

## REMARKS

### \*\*\* VERY INTENSIVE USE\*\*\*

Slight color differences between production batches can occur.

The test results only apply to the samples tested.

Buvetex can't be kept liable for inappropriate use of the fabric.

## PERFORMANCE+

**Designed for high-traffic areas with an elevated risk of soiling and staining, PERFORMANCE+ fabrics are very easy to maintain and practically all kinds of common stains can be easily removed. For easy day-to-day maintenance of your PERFORMANCE+ fabric follow the instructions below.**

### Stain Removal

1. Treat stains as soon as they occur.
2. Remove any excess of soiling material using absorbent paper in the case of spills and oily stains, and a knife or spatula in the case of crusted or dried-on stains.
3. Wipe the stain with a clean cloth using a solution of lukewarm water mixed with a few drops of neutral detergent or handwash.
4. With persistent stains moisten or spray the upholstery fabric directly with soapy water and then rub. Repeat the treatment if necessary.
5. When the stain has disappeared rinse with clear water to remove all soap residue, and rub dry with a clean towel.
6. Let air-dry at room temperature. Do not use hair dryers.

Note: in case water rings or water stains remain after the cleaning, clean the entire surface area of the sofa cover, from seam to seam.

### Machine-washing

1. Wash the sofa covers inside out and with the zipper closed.
2. When the sofa cover uses Velcro instead of a zipper, attach a protective cloth or strip over the Velcro, this to avoid damage to the fabric.
3. Use neutral detergents and do not use softener.
4. Wash at the recommend temperature (in case of doubt, wash at 30° C), using a washing program with delicate cycle.
5. Use minimum centrifugation (800 rpm).
6. Do not wash with other textiles and do not load the washing machine excessively.

### Drying

1. With the cover still moist stretch in both directions.
2. Dry flat at environmental temperature.
3. Avoid direct exposure to sunlight.
4. Always assure that the cover is completely dry before usage.

